

1-PHASE UNITS



The Magnaflux A, AD and ADH Series are our most economical standard wet bench units. They offer great particle mobility for finding surface and sub-surface defects, and the versatility of using AC or DC magnetization (except A-2030). The two outputs are independently adjustable to set each magnetic field, circular or longitudinal. Magnetization shot time is adjustable, allowing better development of indications.

AD-2045

4000 amps AC or 5000 amps 1 Phase FWDC
2 Outputs—Contacts, 12" ID Coil
Voltages Available (208 V or Higher)
Standard Coil May be Substituted for 16", 20", or 25" ID Coil

ADH-2045

4000 amps AC or 5000 amps 1 Phase HWDC
2 Outputs—Contacts, 12" ID Coil
Voltages Available (208 V or Higher)
Standard Coil May be Substituted for 16", 20", or 25" ID Coil

A-2030

3000 amps AC
2 Outputs—Contacts, 12" ID Coil
Voltages Available (208 V or Higher)
Standard Coil May be Substituted for 16" or 20" ID Coil